



NOTES:

1. EXTEND MEMBRANE TO EXCEED ANTICIPATED ICE DAM HEIGHT.
2. CAREFULLY POSITION MEMBRANE AT ROOF PERIMETER WHEN INSTALLING METAL DRIP EDGE.
3. INSTALL WIP IN SHINGLE FASHION EDGE SPLICE IS 3 1/2" MIN. END SPLICE 6" MIN.

WIP-1

RAKE AND EAVE



© 2013 CARLISLE CORPORATION