



NOTES:

1. EXTEND MEMBRANE TO EXCEED ANTICIPATED ICE DAM HEIGHT.
2. INSTALL WIP IN TRANSITION AREA FIRST, THEN COVER WITH METAL FLASHING AND SHINGLES.
3. WIP IS NOT INTENDED FOR EXPOSED FLASHING APPLICATIONS.
4. INSTALL ROOFING SHINGLES PER MANUFACTURERS INSTRUCTIONS

WIP-2

ROOF TO WALL TRANSITION



© 2013 CARLISLE CORPORATION