



- NOTES:
1. CENTER MEMBRANE OVER VALLEYS AND RIDGES STARTING AT THE LOW POINT FOR LAPS TO SHED WATER.
  2. AVOID FASTENERS IN THE VALLEY.

WIP-3

VALLEYS



© 2013 CARLISLE CORPORATION