



NOTES:

1. EXTEND MEMBRANE TO EXCEED ANTICIPATED ICE DAM HEIGHT.
2. COVER MEMBRANE WITH METAL STEP FLASHING OR SHINGLES.

WIP-4

DORMERS



© 2013 CARLISLE CORPORATION