



NOTES:

1. CUT THE WIP MEMBRANE TO FIT SECURELY AROUND PENETRATION.
2. INSTALL FLASHING OR LEAD BOOT OVER WIP DURING LAYING OF SHINGLES.

WIP-6

PIPE PENETRATION

CARLISLE
WIP PRODUCTS

© 2013 CARLISLE CORPORATION