

GROUP WIP-1

DETAIL SEALANTS THAT CAN GO OVER OR UNDER* WIP PRODUCTS, *UNLESS OTHERWISE NOTED

BARRIBOND
BARRIBOND HP
BARRIBOND XL
CCW-LM 800XL
PECORA DYNATROL II
DYMONIC FC OR DYMERIC 240FC

CCW-201
CCW-GREENBOND WB
NOVALINK BY CHEMLINK
OTHERS AS APPROVED BY CARLISLE

GROUP WIP-2

SILICONE SEALANTS – APPLICATION OVER WIP PRODUCTS ONLY

DOWSIL 756, 758, 790, 791, 795
PECORA 890, 895 & AVB SILICONE

GE SILPRUF SCS 2000, SILPRUF SCS 9000
TREMCO SPECTREM 1, SPECTREM 3
OTHERS AS APPROVED BY CARLISLE

NOTES:

1. FOLLOW APPLICATION INSTRUCTIONS BY SEALANT MANUFACTURER
2. DO NOT INSTALL 1-PART SEALANTS INTO JOINTS EXCEEDING ½" DEPTH
3. ALLOW ALL SEALANTS TO CURE A MINIMUM OF 16 HOURS BEFORE COVERING WITH THE WIP UNDERLAYMENT NOTING THAT AMBIENT TEMPERATURE WILL AFFECT SEALANT CURE TIME. MORE TIME MAY BE REQUIRED PRIOR TO APPLICATION OF THE WIP UNDERLAYMENT.

WIP-0A

WIP PRODUCTS
APPROVED SEALANTS



© 2023 CARLISLE CORPORATION